

WOODLAND TOTE

AGF studio

TOTE DESIGNED BY AGF STUDIO



hello, bear



FABRICS DESIGNED BY

Bonnie
Christine



C-5434
BUCK FOREST




HBR-5433
FIREFLY WHISPER



DEN-T-3000
BLUEBOTTLE FIELD



DEN-L-4000
SOFT SAND



PE-433
SNOW

Project was sewn on a BERNINA 550 Quilters Edition

ADDITIONAL MATERIALS

- Zipper Foot #4
- All Purpose Ivory 22" Zipper
- Fusible Fleece
- Threads: Black and Ivory thread

FABRIC REQUIREMENTS

Fabric A	C-5434	½ yd.
Fabric B	HBR-5433	1 yd.
Fabric C	DEN-T-3000	½ yd.
Fabric D	DEN-L-4000	¼ yd.
Fabric E	PE-433	Fat QT.



CUTTING DIRECTIONS

- Two (2) 4 1/2" x 14" strips from Fabric C (top front and back bag)
- One (1) 4 1/2" x 14" strip from B (Lining top front)
- Two (2) 13" x 14" rectangle from Fabric A (bottom front and back bag)
- One (1) 13" x 14" rectangle from Fabric B (lining) and E (interlining)
- Four (4) Bag Corners from Fabric C
- One (1) 4" x WOF from Fabric C (exterior side panel)
- Two (2) 4" x 25" strips from Fabric B (lining side panel)
- One (1) 4" x 49" strip from Fusible Fleece (lining side panel)
- Three (3) 14" x 16 1/2" rectangles from Fabric B (backing piece front bag and lining)
- Two (2) 14" x 16 1/2" rectangles from Fusible Fleece (lining)
- Two (2) 5" x 27" strips from Fabric D (straps)

CONSTRUCTION

Step 1: Sewing the Straps

- Take a 5" x 27" strip from Fabric D and place glue side of fusible fleece to the wrong side of your strip. Iron fusible fleece to strip.
- For this project we will be sewing with thicker fabrics and fusible fleece. To make sewing easier I like to use my walking foot.
- Insert the foot sideways from right behind the needle, placing the fork up over needle clamp and the shank under the positioning cone. Attach by securing the clamp lever.

- Also using a 90/14 needle or a jean needle may help when sewing with AGF Canvas and Denim.
- Next fold strip in half lengthwise with right sides together and sew at 1/2" seam allowance.
- To flip strap through to the right side of the fabric take a safety pin and pin to the end of your strip and feed the safety pin through your strap and inch your way through strap pulling the fabric through.
- Once strap is flipped to the right side of the fabric press strap flat. Repeat this same process with the other strap.
- To quilt your straps at 1/4" move your needle position all the way to the left and change your stitch length to 4.
- Place your strap on the right inside edge of your walking foot and sew straight down to the end of your strap.
- Place the right inside edge of your walking foot right against the line you just stitched.
- Follow the stitch line until you get to the end of your strap.
- Follow this same process quilting 1/4" lines until you get to the end of your strap.

Step 2: Sewing you Zipper

- Attach your zipper foot to your machine, Foot number 4.
- To be able to sew with your zipper foot push the home button.
- Use the arrow keys to get to the creative consultant button. Press ok.
- Select the icon for Heavy weight woven fabrics and press ok.
- Use the arrow keys to select the zipper function. Press ok and now your machine is programed with the proper settings to sew your zipper.

- Center zipper facing down on 13" x 14" rectangle from Fabric A.
- Take 13" x 14" rectangle from Fabric B and place 13" x 14" rectangle from Fabric F on the wrong side of Fabric B.
- Place on top of zipper and rectangle from Fabric A. Pin and stitch right up against the zipper.
- Press seam allowance towards Fabric B and edge stitch as close to the edge of the fabric B to stitch down the seam allowance. This will help to keep the lining down and out of the way of the zipper when unzipping or zipping your zipper.
- Repeat this same process for the top part of your zipper. Take 4 1/2" x 14" strip from Fabric C and place right sides together to your zipper.
- Take the right side of your lining piece and place on the back side of your zipper and pin piece together sandwiching the zipper in the middle.
- Press seam allowance away from zipper and edge stitch seam allowance down.
- Take backing piece, 13" x 16 1/2" rectangle from Fabric B, place front bag on top. Unzip zipper half way and pin pieces together and sew along each side to secure the backing.
- Make sure to sew slowly when going over the zipper ends. After sewing the backing to the front bag you will have nicely finished front zipper pocket.

Step 3: Sewing the Bag Corner

- Take two bag corners and place them right side together and sew at the curve at 1/2". Clip seam allowance around curve in order to have a nice curve that lays flat. Flip piece so wrong sides are touching, press curved seam. Repeat this same process for the other two corner pieces.
- Place and pin corner pieces at the bottom of your front bag.
- Next we are going to topstitch corner piece to bag at 1/4" with our black thread.
- We are going to echo this 1/4" stitch until it fills the corners of our bag. Trim each corner.

Step 4: Sewing the Back Bag

- Sew a 4 1/2" x 14" strip from Fabric C to a 13" x 14" rectangle from Fabric A at 1/2" seam allowance.
- Press seam down towards Fabric A and topstitch seam down.
- Take front back and lay on top of back bag, trim back bag to be the same size as the front bag.
- Also take your two lining pieces from Fabric B and your 14" x 16 1/2" fusible pieces and cut to size as well.

Step 5: Sewing the Lining

- Sew both 4" x 25" strips together at 1/2" and iron 4" x 49" strip fusible fleece to the wrong side of the fabric. Also iron fusible fleece to both of your lining pieces.
- Find the midpoint of your lining and line up seam on your side panel and pin side panel to your lining piece. Sew at 1/2" .
- Repeat this same process to secure your other lining piece to your panel but leave a small unsewn portion to flip right side of bag through. Trim off excess side panel.

Step 6: Sewing the Exterior Bag

- Take your straps and pin straps 3" in from each side seam and sew into place.
- Repeat this same process with your other strap and your front bag.
- Repeat this same process we used to secure our lining side panel to secure the side panel to your exterior piece. When panel is sewn into place trim excess zipper.

Step 7: Sewing the Exterior to the Lining

- Take your exterior bag and place right sides together inside of your lining.
- Match up side seams and pin all the way around your top bag. Sew all the way around your top bag at 1/2".
- Flip right side of the bag though the unsewn portion in the lining.
- Machine or hand stitch lining closed.
- Topstitch top of bag to keep lining laying nice and flat inside your bag.



XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX

*Congratulations
& enjoy*

XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX



artgalleryfabrics.com

NOTE: While all possible care has been taken to ensure the accuracy of this pattern, We are not responsible for printing errors or the way in which individual work varies. Please read instructions carefully before starting the construction of this quilt. If desired, wash and iron your fabrics before starting to cut.

© 2016 Courtesy of Art Gallery Quilts LLC. All Rights Reserved.